



Kit 1040

FORD Galaxy, 5-dr MPV, 96-00


SEAT Alhambra, 5-dr MPV, 96-00

VOLKSWAGEN Sharan, 5-dr MPV, 96-00



480R
754







480








750




THULE[®]
SWEDEN






3





754



750



1




2




	X
FORD Galaxy, 5-dr MPV, 96-00	39
SEAT Alhambra, 5-dr MPV, 96-00	39
VOLKSWAGEN Sharan, 5-dr MPV, 96-00	39

1



2



	Y
FORD Galaxy, 5-dr MPV, 96-00	35,5
SEAT Alhambra, 5-dr MPV, 96-00	35,5
VOLKSWAGEN Sharan, 5-dr MPV, 96-00	35,5




480R




480

1




2




	X inch	X mm
FORD Galaxy, 5-dr MPV, 96-00	41 "	1041 mm
SEAT Alhambra, 5-dr MPV, 96-00	41 "	1041 mm
VOLKSWAGEN Sharan, 5-dr MPV, 96-00	41 "	1041 mm

1



2
















	Y inch	Y mm
FORD Galaxy, 5-dr MPV, 96-00	39 5/8 "	1006 mm
SEAT Alhambra, 5-dr MPV, 96-00	39 5/8 "	1006 mm
VOLKSWAGEN Sharan, 5-dr MPV, 96-00	39 5/8 "	1006 mm

4


FORD Galaxy, 5-dr MPV, 96-00

SEAT Alhambra, 5-dr MPV, 96-00




VOLKSWAGEN Sharan, 5-dr MPV, 96-00



5



	X mm	Y mm	X inch	Y inch
FORD Galaxy, 5-dr MPV, 96-00	400 mm	700 mm	15 3/4"	27 1/2"
SEAT Alhambra, 5-dr MPV, 96-00	400 mm	700 mm	15 3/4"	27 1/2"
VOLKSWAGEN Sharan, 5-dr MPV, 96-00	400 mm	700 mm	15 3/4"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternadamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		